



HURRICANE / SANTA ANA COVER REMOVAL / REFITTING

Please see the below instructions for removing and fitting a parasol cover for a centre pole Hurricane or Santa Ana parasol.

If you have any problems, or questions during the change over , please feel free to contact us for advice using the email address at the bottom of the page.

Before starting to remove the cover, make sure that the parasol is in a secure position or is laid down to avoid risking damage to the umbrella or yourself.

To begin the removal, first unscrew the finial from the top of the parasol and put it in a safe place.

Next remove the rib end screws using a phillips screw driver. Make sure to keep the screws in a safe place as you will need them to put the cover back on.



Once the finial and rib screws have been removed the cover can be slipped off the frame.

To refit the parasol, simply reverse the procedure.